



A/V Equipment **DO NOT WANT**



VCRs
of any kind



Cut cord and take to **CBM**

DVD / VCR
Combos
of any kind



Cut cord and take to **CBM**

DVD, Blu-Ray, or
CD Players
Missing Remotes



Cut cord and take to **CBM**

Portable
DVD Players
of any kind



Take to **Recycling**
All-in-One Shelf

Cassette Tape
Decks



Cut cord and take to
Advanced Recycling Pallet

Clock Radios
especially Sharper Image




Take to **Recycling**
All-in-One Shelf

Anything Broken,
Gross, or Missing Parts



Cut cord and take to **Advanced Recycling Pallet** or **CBM**





A/V Equipment **DO NOT WANT**



Cheap Speakers

- usually plastic or particle board
- skinny wire attached
- often paired with those ----->



Cut cord and take to
Advanced Recycling Pallet

Cheap All-In-One Stereos of any kind



Cut cord and take to
Advanced Recycling Pallet

Small FM, CD, or Cassette Boomboxes



Cut cord and take to
Advanced Recycling Pallet

DVRs, Cable or Satellite Boxes of any kind



Cut cord and take to
System Eval for Hard Drive
removal

Satellite Radios or Car Stereos of any kind



Take to **Recycling
All-in-One Shelf**

Record Players Broken, Gross, or Missing Needle



Cut cord and take to
Advanced Recycling Pallet

